

Why can't I see the section that I need in the risk assessment?

The layout of the risk assessment is defined by the information that has been registered for the supply. If you are missing a section it may be that the register is incorrect.

To check, return to the front page for that supply (click on the name of the supply at the top of the page). You can quickly check the number of sources, tanks and properties that are registered in the dark blue area at the top of the page. If this is incorrect, click on *Edit Supply* and work through the sections to make sure that everything is correct.

You can only add elements of the supply in this section, so make sure everything is correct before you return to the risk assessment.